

Assembly Manual- Narrow Scaffold

N

1




Insert the adjustable wheels into the legs of the frame. Lock the wheels with the lock pins, and brakes.

6



Move the platform with the hatch onto 1st rung of the 3 or 5 rung ladder frames.

2



Position the ladder frame as shown. Lock the wheels, and clip the horizontal braces onto the rungs.


7



Add the adjustable stabilisers, then lock them entirely. Do not climb the platform until fully guardrailed.

A typical 5.0m high Narrow Scaffold
Other Sizes and Combinations Available

3




Install diagonal braces as shown. Ensure scaffold is level & plumb using a spirit level. Frame will now be self supporting.

8




Add next lift of 3 or 5 rung ladder frames & next diagonal braces. Add next platform with hatch onto the 1st rung of 3 or 5 rung ladder frames.




Ladders omitted for clarity.

4



Install the platform with hatch on 4th rung of the five rung ladder frame.

9



Erect guardrails and horizontal braces. Guardrails should be 0.5m and 1.0m above the platform in all cases.

5



Add next lift of 3 or 5 rung ladder frames & next diagonal braces. Do not climb the platform until fully guardrailed.

10



Move the second platform with hatch onto the 3rd rung of the 3 or 5 rung ladder frames. Fit toeboards to all working platforms.

IMPORTANT: It is the operator's duty to inspect the components for damage before each use. Avoid contact with acid as this will damage the aluminium beyond repair. Avoid leaving the platform out under constant sun's light and rain to prevent delamination. In accordance with Australian Standard 1576 the operator requires a scaffold ticket to erect scaffold above 4 metres standing height.